

Santa Fe Hybrid

Model Year 2024 onwards

Emergency Response Guide



HYUNDAI HELP LINE
0800 HYUNDAI (498 632)

WARNING

- If severe damage causes high-voltage components to become exposed, emergency responders should take appropriate precautions and wear appropriate insulated personal protective equipment.
- Do not attempt to remove the safety plug while standing in the water.
- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow any of these instructions may result in serious injury or death by electrocution.

- Do not cut through any component of the Airbag (SRS) system (Supplementary Restraint System)
- SRS components may remain powered and active for up to 3 minutes after the 12V electrical system is shut off or disabled.

Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.

Failure to follow any of these instructions may result in serious injury or death from accidental deployment of the airbag system.

This manual includes information titled as DANGER, WARNING, CAUTION & NOTICE.

These titles indicate the following:

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.

WARNING

- If severe damage causes high-voltage components to become exposed, emergency responders should take appropriate precautions and wear appropriate insulated personal protective equipment.
- Do not attempt to remove the safety plug while standing in the water.
- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow any of these instructions may result in serious injury or death by electrocution.

- Do not cut through any component of the Airbag (SRS) system (Supplementary Restraint System)
- SRS components may remain powered and active for up to 3 minutes after the 12V electrical system is shut off or disabled. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.

Failure to follow any of these instructions may result in serious injury or death from accidental deployment of the airbag system.

This manual includes information titled as DANGER, WARNING, CAUTION & NOTICE.

These titles indicate the following:

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.

WARNING

- If severe damage causes high-voltage components to become exposed, emergency responders should take appropriate precautions and wear appropriate insulated personal protective equipment.
- Do not attempt to remove the safety plug while standing in the water.
- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow any of these instructions may result in serious injury or death by electrocution.

- Do not cut through any component of the Airbag (SRS) system (Supplementary Restraint System)
- SRS components may remain powered and active for up to 3 minutes after the 12V electrical system is shut off or disabled. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.

Failure to follow any of these instructions may result in serious injury or death from accidental deployment of the airbag system.

Contents

Important Safety Information	1 / 2
Introduction	3
SANTA FE Hybrid Identification	4
- General Vehicle Description	4
- Identifying a Hyundai hybrid vehicle	5
SANTA FE Hybrid Main Systems	9
- Key Specifications	9
- Vehicle Components Location	10
- Vehicle Components	14
- Airbag system (SRS : Supplemental Restraint System)	19
Emergency Procedures	21
- Initial response: Identify, Immobilise and Disable	21
- Extraction Operations	29
- Submersion	30
- Vehicle Fire	31
- High-Voltage Battery Damage and Fluid Leaks	32
Roadside Assistance	
- Towing	33
- Jump Starting	34

Document Purpose

The purpose of this document is to familiarise emergency responders and the towing/roadside assistance industry with the proper methods to handle the Hyundai SANTA FE Hybrid in an emergency situation. This guide offers a basic overview of key vehicle systems and provides instructions for dealing with the different types of situations encountered by emergency responders. The emergency response procedures for this vehicle are somewhat similar to a conventional vehicle with additional information provided on dealing with the high-voltage electrical system.

Vehicle Description

As with other Hybrids, the Hyundai SANTA FE Hybrid uses a conventional petrol powered internal combustion engine paired with a high-voltage electric motor to propel the vehicle. The high-voltage electrical system is completely self-contained and does not need to be recharged by an external power source such as a charging station through charging port. The high-voltage battery is recharged while the vehicle is being driven. This is accomplished through the use of a generator that produces electricity during driving and braking.



General Vehicle Description

The Hyundai SANTA FE Hybrid is built on a conventional SANTA FE chassis and therefore the five door hatch back looks very similar to its conventional counterpart with a few notable exceptions. The safest method is to assume that any SANTA FE you respond to could be a hybrid vehicle until proven otherwise. Using the information provided in this section, responders will be able to differentiate between the two.

Identifying a Hyundai hybrid vehicle


“HYBRID” badge on the boot / tailgate of the vehicle

The Hyundai SANTA FE HYBRID can be easily identified by the ‘HYBRID’ and the ‘SANTA FE’ badge located on the tailgate of the vehicle.

⚠ DANGER

Electrocution Risk



Badging can become hidden after a crash due to damage to the vehicle. Always be sure to utilise additional methods if identification before determining there is no badge present.



VIN number

The Vehicle Identification Number (VIN) identifies the Electric Vehicle with a “1” (*Number one*) displayed in the 8th position, as shown in the below drawing.

The VIN is punched on the floor under the driver seat. The number “1” in the 8th character of the VIN indicates that it is a hybrid vehicle with a 1.6ℓ Turbo Petrol Engine.



VIN stamped in frame, under driver's seat



VIN Label, front windscreen passenger side



VIN Label, front passenger “B-Pillar”

Engine Compartment

The SANTA FE Hybrid has a plastic air cleaner assembly with “HYBRID” clearly shown on it.



Additionally, there are orange coloured high-voltage electrical cables in the engine compartment.










Vehicle Underside

An orange coloured cable covered by the under cover is also visible on the underside of the vehicle. This cable runs from the center of the vehicle to the engine compartment.



Hybrid Vehicle Cluster Instrument Panel


The Hybrid Vehicle Instrument Cluster Panel displays the electric vehicle specific features that identify the SANTA FE as a Hybrid vehicle.



Key Specifications

Item		Hybrid
Engine	Type	GAMMA 1.6ℓ TURBO ATKINSON GDI (Gasoline Direct Injection)
		Displacement : 1,598 cc
	Max. Power (kW)	132 kW @ 5,500 rpm
	Max Torque (Nm)	265 Nm @ 1,500 ~ 4,000 rpm
Transmission	Type	6-Speed Automatic Transmission (with HTRAC)
Electric Traction Motor	Type	Permanent Magnet Synchronous Motor
	Max. Power (kW)	44.2 kW (combined – 169 kW)
	Max Torque (Nm)	264 Nm (combined – 350Nm)
High Voltage Battery	Type	Lithium-ion Polymer (Pouch Type)
	Rated Voltage (V)	240
	Capacity (kWh)	1.49
	Number for Cells	16 Cells (4 Modules)
	Weight (kg)	Approx. 15

Vehicle Components Location



HPCU	Hybrid Power Control Unit
Hybrid Motor	When current flows through the coil. It generates a rotating magnetic field and generates motor torque.
H.V. Battery	Supplies electric energy to traction motor and stores generated electric energy.
H.V. Cable	The high-voltage cabling is orange per the SAE standard.

⚠ WARNING

Electrocution Risk!

- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow these instructions can lead to death by electrical shock.


WARNING

Electrocution Risk!

- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow these instructions can lead to death by electrical shock.

Vehicle Components



High-Voltage (HV) Battery

The High-Voltage battery is located under the vehicle, below the driver's seat.

BMS (Battery Management System)

The BMS is located inside the High-Voltage Battery assembly and measures several parameters to maintain the optimal performance of the High-Voltage Battery.

In addition, if a system fault occurs, the BMS turns off the PRA to protect the system.

PRA (Power Relay Assembly)

The PRA is located inside the High-Voltage Battery Pack Assembly and controls the high-voltage power circuit between the High-Voltage Battery and the Hybrid Power Control Unit.

12V Auxiliary Battery

The 12V auxiliary battery is located below the luggage (boot) mat.

WARNING

Electrocution Risk!

- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow these instructions can lead to death by electrical shock.

Petrol Engine

Specially calibrated internal combustion engine 1.6-litre Turbo GDI direct injection petrol engine. Santa Fe Hybrid is powered by this engine and an electric drive motor, which uses energy stored in the battery. Santa Fe Hybrid cannot be plugged in to charge the high voltage battery. Instead, the battery is charged through regenerative braking and by the internal combustion engine.



Electric Drive Motor

Mounted between the petrol engine & automatic transmission. Electric Drive Motor is used for vehicle propulsion when in EV mode & Hybrid Mode. During deceleration or braking, it acts as a generator and charges the high voltage battery by converting the vehicle's kinetic energy into electrical energy.




Transmission

The 6-speed Automatic Transmission is mated to the Electric Drive Motor and then provide the driveline to the front & rear wheels (all-wheel drive) *HTRAC*.



Lithium-ion High Voltage Battery

The 1.49 kWh high-power battery has superior charge/discharge characteristics, maximising both electric driving and energy regeneration



WARNING

Electrocution Risk!


- Never cut or disconnect the high voltage orange cabling and connectors without first disabling the system by removing the safety plug.
- Exposed cables or wires may be visible inside or outside the vehicle. Never touch the wires, cables, connectors, or any electric components before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow these instructions can lead to death by electrical shock.

Airbag system (SRS : Supplemental Restraint System)

Airbag

Seven airbags are installed in the SANTA FE Hybrid as shown below. Before starting any emergency procedure, make sure the vehicle ignition is turned off, disconnect the negative cable from the 12V auxiliary battery to prevent accidental deployment of airbags.



*** The actual air bags and seats in the vehicle may differ from the illustration**


1. Driver's front airbag
2. Passenger's front airbag
3. Front side airbag
4. Rear side airbag
5. Curtain airbag
6. Driver's knee airbag
7. Front centre side airbag

Seat Belt Pretensioners

The SANTA FE Hybrid is equipped with seat belts with pretensioners. When the seat belt pretensioners are activated in a collision, a loud noise may be heard and fine dust, which may appear to be smoke, may be visible in the passenger compartment. These are normal operating conditions and are not hazardous. The seat belt pretensioner assembly mechanisms may become hot during activation, and may need several minutes to cool after they have been activated.

Sensors and Control Module

The airbags and pretensioners are managed by the SRS Control Module, or SRSCM, which is located below the front of the center console. In addition, there are four side impact sensors : two conventional accelerometer sensors in the B-pillars, and two pressure sensing sensors inside of the front door modules.



⚠ WARNING

- Do not cut through any component.
- SRS components may remain powered and active for up to 3 minutes after the 12V electrical system is shut off or disabled. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.

Failure to follow any of these instructions may result in serious injury or death from accidental deployment of the airbag system.

Initial Response:


The following procedures should be used whenever you are dealing with a SANTA FE Hybrid at an emergency scene. All other operations should be consistent with your department's standard operating procedures or guides. Hybrid vehicles damaged by a crash may have compromised high voltage safety systems and present a potential high voltage electrical shock hazard. Exercise caution and wear appropriate personal protective equipment (PPE) safety gear, including high voltage safety gloves and boots. Remove all metallic jewelry, including watches and rings.

Identify

When dealing with a SANTA FE at the scene of an accident, emergency responders should always assume that it is a electric model until it can be proven otherwise using the identification features outlined in this ERG. External badging will usually be the first clue but it can often be hidden by damage caused in a crash. Always be sure to inspect multiple sides of the vehicle as well as using the clues found under the hood and in the interior of the vehicle.

Immobilise

The next step is to immobilise the vehicle to prevent any accidental movement that can endanger the emergency response personnel and any crash victims. Since the SANTA FE Hybrid has the ability to shut down the petrol engine when it is not needed, there will be instances where the vehicle appears to be off because of the absence of engine noise. When in its “EV Ready” mode, the vehicle can move almost silently using the electric motor alone. Responders should approach the vehicle from the sides and stay away from the front or rear as they are both potential paths of travel. Instructions for immobilising the vehicle are shown below.



Rotary Gear Shifter
- Push the park
position



Engage Parking Brake



Chock the Wheels

Disable

The final step in the initial response process, conducted after the vehicle is secured to prevent movement, is to disable the vehicle, its SRS components and the high voltage electrical system. To prevent current flow through the system, use one of the following procedures to disable the vehicle.


I . Disabling the system – Smart Key System and “POWER” START/STOP BUTTON

1. 1. Check the status of the EV READY light on the instrument panel. If the EV READY light is illuminated, the vehicle is on.

(Refer to page 5)

a) If the EV READY light is NOT illuminated, the vehicle is off, Do not push the “POWER” START/STOP button because the vehicle may restart.

b) To turn off the system, put the shift lever in the P (Park) position and press the POWER button beside a shift lever.



“POWER” START/STOP Button

Without depressing the brake pedal

Pressing POWER button	Button Position	Vehicle condition
	OFF	Off
One time	ACC	Electrical accessories are operational.
Two times	ON	The warning lights can be checked before the vehicle is started.
Three times	OFF	Off

Depressing the brake pedal while a shift lever is in the P (Park) position

Pressing POWER button	Button Position	Vehicle condition
	OFF	Off
One time	-	Ready to drive

2. Before disconnecting the 12V auxiliary battery, move the smart key at least 2 meters away from the vehicle to prevent accidental restart.




Smart Key

3. Disconnect the negative (-) 12V auxiliary battery cable (A), located in the boot area, under the boot mat, to further prevent the risk of accidental restart.



3-1. Remove the luggage mat (A).



3-2. Remove the 12V battery service cover (B).



3-3. Turn the ignition switch OFF and disconnect the auxiliary 12V auxiliary battery negative (-) terminal (C).

NOTICE

If necessary, lower the windows, unlock the doors and open the boot as required, before disconnecting the 12V auxiliary battery. Once the 12V auxiliary battery is disconnected, power controls will not operate.



WARNING

Wait for more than 3 minutes so that the capacitor in the high voltage system can be fully discharged.


II. Disabling the system – IG Relay Removal (Alternate Method)




4. Separate the negative (-) 12V battery cable (A), located at the luggage room, to further prevent the risk of accidental restart., to further prevent the risk of accidental restart.



4-1. Remove the luggage mat (A).



4-2. Remove the 12V battery service cover (B).



4-3. Turn the ignition switch OFF and disconnect the auxiliary 12V auxiliary battery negative (-) terminal (C).

NOTICE

If necessary, lower the windows, unlock the doors and open the boot as required, before disconnecting the 12V battery. Once the 12V battery is disconnected, power controls will not operate.

⚠ WARNING

Wait for more than 3 minutes so that the capacitor in the high voltage system can be fully discharged.

If both methods of disabling system are unsuccessful, the vehicle is not secured from accidental deployment of airbags and electric shock from high-voltage components.

WARNING Electrocutation Risk!

- Before engaging in emergency response procedures, ensure the vehicle is disabled and wait for more than 3 minutes to allow the capacitor in the high voltage system to discharge to avoid electrocution.
- Exposed cables or wires may be visible inside or outside the vehicle. To prevent injury or death due to electrical shock, never touch the wires or cables before disabling the system, to prevent injury or death due to electrical shock.

Failure to follow any of these instructions may result in serious injury or death by electrocution.

WARNING Explosive Risk!

- Do not cut through any component.
- SRS components may remain powered and active for up to 3 minutes after the 12V electrical system is shut off or disabled. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.


Failure to follow any of these instructions may result in serious injury or death from accidental deployment of the airbag system.

Lifting / Jacking Operations

The lifting / jacking up for the SANTA FE Hybrid are similar to the conventional vehicle. However, the first responder should pay special attention when they extract occupants in the vehicle. Before extrication operations, the first responders should carry out “Initial Response: Identify, Immobilise and Disable” procedure section from pages 22 - 26.


Vehicle Stabilisation

Use standard stabilisation (cribbing) points, as shown. Always be sure to connect to a structural member of the vehicle and avoid placing cribbing under high voltage cables, fuel lines and other areas not normally considered acceptable.




Extrication Tools & Procedure

When responding to an incident involving an SANTA FE Hybrid, we recommend that the first responders follow their organization's standard operating procedures for assessing and dealing with vehicle emergencies. When the first responders cut the vehicle, they should always pay special attention to airbag system, orange coloured high voltage cables and other high voltage components to avoid damage to parts which may increase the risks of explosion.



Airbag



High Voltage System



Pre-tensioner (Belt & EFD)



Ultra High Strength Steel
(hot stamped steel)

Submersion

Some emergency responses can involve a submerged vehicle. A SANTA FE Hybrid that is submerged does not have high-voltage component on the vehicle's body or framework. It is safe to touch the vehicle's body or framework if there is no severe damage to the vehicle, whether it is in water or on land.

In the event the vehicle is submerged or partially submerged, remove the vehicle from the water before attempting to disable the vehicle. Drain the water from the vehicle. Use one of the methods described in sections of page 22 - 26 to disable the vehicle.

WARNING

- If severe damage causes high-voltage components to become exposed, responders should take appropriate precautions and wear appropriate insulated personal protective equipment.
- Do not attempt to remove a Service Disconnect Plug while in the water

Failure to follow any of these instructions may result in serious injury or death by electrocution.

Vehicle Fire

After Initial Emergency Response Procedures have been applied, Firefighting Procedures may begin. Hyundai recommends that each response team follow their own department's standard operating procedures for fighting vehicle fires in combination with the SANTA FE Hybrid specific details that are covered in this section.

Firefighting Operations

If the high-voltage battery pack is either involved in or at risk of being involved in a fire in a SANTA FE Hybrid, strict cautions must be taken while conducting firefighting operations due to following reasons:

Lithium-ion Polymer batteries contain gel electrolyte that can vent, ignite, and produce sparks when subjected to temperatures above 150°C

May burn rapidly with a flare-burning effect.

Even after the high-voltage battery fire appears to have been extinguished, renewed or delayed fire can occur.

- Use a thermal imaging camera to ensure the high voltage battery is completely cooled before leaving the incident.
- Always advise second responders that there is a risk of the battery re-igniting.
- Fire, submersion or a collision that has compromised the high voltage battery, always store it in an open area with no exposures within 50 feet / 15 meters.

A burning battery could release hydrogen fluoride, carbon monoxide, and carbon dioxide gasses. Use NIOSH/MSHA approved full-face self-contained breathing apparatus (SCBA) with full protective gear. Even if the high-voltage battery pack is not directly involved in a vehicle fire, approach the vehicle very carefully.

Extinguishers

Small fires that high voltage battery is not involved : Extinguish fires using a ABC extinguisher for an electric fire.

Fires that the high voltage battery is involved, or the high voltage battery is heating : Extinguish fires using large and sustained amount of water to cool the high voltage battery. Do not extinguish fire with a small amount of water. Firefighters should not hesitate to pour large amounts of water on the vehicle.

High-Voltage Battery Damage and Fluid Leaks

The HV Battery assembly is enclosed in a sturdy metal case that is rigidly mounted to structural components of the vehicle. This construction helps prevent damage to the HV Battery assembly even in severe crashes. This section provides emergency responders with information regarding how to mitigate the severity of a damaged High Voltage Battery assembly or gel electrolyte spill, however unlikely that might be.

- Cease all smoke, spark, flame activity around the vehicle.
- Electrolyte solution is a skin irritant.
- Do not touch or step on the spilled electrolyte.
- If electrolyte leak occurs, wear appropriate solvent resistant PPE and use oil, sand, or a dry cloth to clean up the spilled electrolyte. Be sure to adequately ventilate the area.

WARNING Irritant Substance Risk!

- Internal components of the High Voltage Battery are irritants and sensitizers.
- To avoid contact with these irritants and sensitizers wear positive pressure self-contained breathing apparatus (SCBA) and other personal protective equipment (PPE) designed for use with these types of hazards.

Failure to wear proper SCBA and PPE can result in serious injury or death


- Electrolyte solution is an eye irritant – If contact with eyes, rinse with plenty of water for 15 minutes.
- Electrolyte solution is a skin irritant. Therefore, if there is contact with skin, wash off with soap.
- Electrolyte liquid or fumes that have come into contact with water vapors in the air will create an oxidized substance. This substance may irritate skin and eyes. In these cases, rinse with plenty of water and see a doctor immediately.
- Electrolyte fumes (when inhaled) can cause respiratory irritation and acute intoxication

Move to a well ventilated location for fresh air and wash mouth with water. See a doctor immediately.

Towing

When towing SANTA FE Hybrid vehicle, all wheels should be off the ground and not in contact with the road.

If emergency towing is necessary, we recommend having it done by an authorised Hyundai dealer or a commercial tow-truck service. The use of wheel dollies or flatbed is recommended.



⚠ CAUTION

- Do not tow the vehicle backwards with the front wheels on the ground as this may cause damage to the vehicle.
- Do not tow with sling-type equipment. Use wheel lift or flatbed equipment.
- Never tow the vehicle with the front wheels on the ground (forward or backward), as this may cause damage to the vehicle.

To Jump Start the Car

Before Jump Starting

1. Press the 12V Battery Reset switch to reconnect the 12V battery.
2. Start the vehicle within 15 seconds of pressing the 12V Battery Reset switch.
3. After starting vehicle (READY indicator on), operate the vehicle safely outdoors in ready mode stopped and/or drive it for 30 minutes total to charge the 12V battery fully.

NOTICE

If you do not start the vehicle immediately after pressing the 12V Battery Reset switch, the power of 12V battery is automatically disconnected after few seconds to save the 12V battery from additional discharge. If the 12V battery is disconnected prior to starting the vehicle, press the 12V Battery Reset switch again and then immediately start the vehicle as explained above.

⚠ CAUTION

- Do not connect the cables to or near any part that moves when the vehicle is started.
- Do not allow the jumper cables to contact anything except the correct battery terminals or the correct ground.
- Do not lean over the battery when making connections.

Jump Starting

If the 12V battery is over discharged to a point that the reset does not work, try to jump-start the vehicle.

1. Position the vehicles close enough that the jumper cables will reach, but do not allow the vehicles to touch.
2. Avoid fans or any moving parts in the engine compartment at all times, even when the vehicles are turned off.
3. Turn off all electrical devices such as radios, lights, air conditioning, etc. Put the vehicles in P (Park) and set the parking brakes. Turn both vehicles OFF.

4. Connect the jumper cables in the exact sequence shown in the illustration. First connect one jumper cable to the red, positive (+) jumper terminal of your vehicle (1).


5. Connect the other end of the jumper cable to the red, positive (+) battery/jumper terminal of the assisting vehicle (2).

6. Connect the second jumper cable to the black, negative (-) battery/chassis ground of the assisting vehicle (3).


7. Connect the other end of the second jumper cable to the black, negative (-) chassis ground of your vehicle (4). Do not allow the jumper cables to contact anything except the correct battery or jumper terminals or the correct ground.

8. Start the engine of the assisting vehicle and let it run for a few minutes.

9. Start your vehicle as soon as possible. After starting vehicle (READY indicator on), operate the vehicle safely outdoors in ready mode stopped and/or drive it for 30 minutes total to charge the 12V battery fully. If the cause of your battery discharging is not apparent, we recommend that the system be checked.



[A] RED cable: (+) battery terminal
[B] BLACK cable: (-) battery terminal



⚠ CAUTION

- Do not connect the cables to or near any part that moves when the vehicle is started.
- Do not allow the jumper cables to contact anything except the correct battery terminals or the correct ground.
- Do not lean over the battery when making connections.

HYUNDAI HELP LINE
0800 HYUNDAI (498 632)